



Description

This procedure details how to download an existing Cortex LT (V1 hardware) file into a Cortex LT (V2 hardware). The V1 file will have a .CLT file extension. The new V2 file has a .LT2 file extension. The Cortex LT V2 uses the CaroLink software.

1. Connect a USB cable from the computer to the Cortex LT.
2. Open the CaroLink software. The software will prompt you to select the device type. Select Cortex LT V2. Ensure the Com Settings in lower left is set to USB. Press OK when done.
3. Under the File pulldown menu, select Open. In the lower right corner, change the file filter from 'Cortex LT V2 files' to 'All files'. Navigate to the location of the Cortex LT (V1 hardware) file. Note that it should have a .CLT file extension. Select the file and click Open.
4. Click the Online button on the toolbar. The software will prompt you to Read, Write, or Cancel. Select Write. A progress bar will be displayed while the parameters are transferred.
5. Under the Cortex LT pulldown menu, select A1: Options. Toggle the Controller Mode parameter to the Run position to place the device in the run mode. Click Close when done.
6. Under the Cortex LT pulldown menu, select Save. After a few seconds, you should receive a confirmation that parameters were successfully saved. This action saves the parameters in the Cortex LT unit.
7. Under the File pulldown menu, select Save As. Enter an appropriate name and select OK. This action saves the parameters to a file on your computer.
8. Click the Offline button on the toolbar. Disconnect USB cable.